

Verification Report

Unit Serial: 1A1903PP010754
Verified: Tue 19-May-2026 09:46:21(655ms) PM
Firmware Version: 6.1.16_sr4
Last Calibrated: 5/20/2026 1:14:58 AM

Report Summary	
Data	<F1>01006141419999961750123110123ABC<F1>21ANU50
Symbology	GS1 DataMatrix
Device Name	DM475-63530E-PIPS-Verif-Lab
Company	Product Identification and Processing Systems, Inc.
Operator	GW4

Verification Grades					
Standard	Grade	Aperture	Wavelength	Lighting	Formal Grade
ISO 15415:2011	1.0 (D)	16	660	45Q	1.0/16/660/45Q
Custom	Fail (Quality)				

Image	General Characteristics
	Matrix Size
	22x22 (Data: 20x20)
	Horizontal BWG
	10%
	Vertical BWG
	8%
	Encoded characters
	41
	Total Codewords
	50
	Data Codewords
	30
	Error Correction Budget
	20
	Errors Corrected
	0
	Error Capacity Used
	0
	Error Correction Type
	ECC 200
	Image
	Black on white
	Nominal X Dim
	20.1 mil
	Pixels per Module
	15.85
	Contrast Uniformity
	73 at module(15,2)
	MRD
	67% (74% - 7%)

GS1 DataMatrix Quality Parameters					
1. Unused Error Correction (UEC)		100.0%	4.0	A	PASS
2. Symbol Contrast (SC)	Ri/Rd (85/4)	81%	4.0	A	PASS
3a. Modulation (MOD)			4.0	A	PASS
3b. Reflectance Margin (RM)			4.0	A	PASS
4. Axial Nonuniformity (ANU)		11.2%	1.0	D	FAIL
5. Grid Nonuniformity (GNU)		1.5%	4.0	A	PASS
6. Fixed Pattern Damage (FPD)			4.0	A	PASS
7. Left 'L' Side (LLS)			4.0	A	PASS
8. Bottom 'L' Side (BLS)			4.0	A	PASS
9. Left Quiet Zone (LQZ)			4.0	A	PASS
10. Bottom Quiet Zone (BQZ)			4.0	A	PASS
11. Top Quiet Zone (TQZ)			4.0	A	PASS
12. Right Quiet Zone (RQZ)			4.0	A	PASS
13. Top Transition Ratio (TTR)		0%	4.0	A	PASS
14. Right Transition Ratio (RTR)		0%	4.0	A	PASS
15. Top Clock Track (TCT)			4.0	A	PASS
16. Right Clock Track (RCT)			4.0	A	PASS
17. Average Grade (AG)		4.0	4.0	A	PASS
18. DECODE			4.0	A	PASS

Codeword	Mode	Result
232	FNC1	<F1>
131	ASCII	01
130	ASCII	00
191	ASCII	61
171	ASCII	41
171	ASCII	41
229	ASCII	99
229	ASCII	99
226	ASCII	96
147	ASCII	17
180	ASCII	50
142	ASCII	12
161	ASCII	31
140	ASCII	10
142	ASCII	12
230	ASCII	SWITCH TO C40 MODE
046	C40	3AB
100, 068	C40	C<xEB>
038, 087	C40	21A
174, 026	C40	NU5
254	C40	C40 UNLATCH
049	ASCII	0
129	ASCII	ASCII PAD
254	ASCII	ASCII PAD
150	ASCII	ASCII PAD
045	ASCII	ASCII PAD
189, 168, 135, 097, 071, 156, 050, 066, 095, 180, 169, 243, 139, 176, 253, 210, 210, 090, 247, 063	ECC	

ASCII Values	
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11
12	12
13	13
14	14
15	15
16	16
17	17
18	18
19	19
20	20
21	21
22	22
23	23
24	24
25	25
26	26
27	27
28	28
29	29
30	30
31	31
32	32
33	33
34	34
35	35
36	36
37	37
38	38
39	39
40	40
41	41
42	42
43	43
44	44
45	45
46	46
47	47
48	48
49	49
50	50
51	51
52	52
53	53
54	54
55	55
56	56
57	57
58	58
59	59
60	60
61	61
62	62
63	63
64	64
65	65
66	66
67	67
68	68
69	69
70	70
71	71
72	72
73	73
74	74
75	75
76	76
77	77
78	78
79	79
80	80
81	81
82	82
83	83
84	84
85	85
86	86
87	87
88	88
89	89
90	90
91	91
92	92
93	93
94	94
95	95
96	96
97	97
98	98
99	99
100	100
101	101
102	102
103	103
104	104
105	105
106	106
107	107
108	108
109	109
110	110
111	111
112	112
113	113
114	114
115	115
116	116
117	117
118	118
119	119
120	120
121	121
122	122
123	123
124	124
125	125
126	126
127	127
128	128
129	129
130	130
131	131
132	132
133	133
134	134
135	135
136	136
137	137
138	138
139	139
140	140
141	141
142	142
143	143
144	144
145	145
146	146
147	147
148	148
149	149
150	150
151	151
152	152
153	153
154	154
155	155
156	156
157	157
158	158
159	159
160	160
161	161
162	162
163	163
164	164
165	165
166	166
167	167
168	168
169	169
170	170
17	

048 049 048 048 054 049 052 049 052 049 057 057 057 057 057 054 049 055 053 048 049 050 051 049 049 048 049 050 051 065 066 067 029 050 049 065 078 085 053 048

	Codewords
--	-----------

[illegible]

*=Fixed by Error Correction

Modulation																							
99	94	98	94	98	94	98	94	99	94	99	95	99	96	99	96	99	95	99	95	99	96	99	99
95	96	84	95	90	96	89	96	84	96	83	95	86	94	90	94	90	95	84	94	90	95	89	99
92	98	96	89	92	97	88	98	98	99	98	84	95	82	91	85	87	97	97	87	87	97	95	96
94	98	87	91	87	97	87	99	99	99	97	92	84	97	96	96	97	82	96	89	95	98	82	99
92	97	81	98	97	97	81	99	98	88	88	94	96	98	81	87	97	86	86	91	87	96	95	96
93	98	98	99	86	81	98	98	82	88	95	87	88	98	96	89	98	97	97	95	93	92	88	98
92	98	74	97	82	98	99	77	96	96	85	96	82	96	83	92	97	81	97	80	90	89	94	96
92	98	97	83	98	99	99	97	89	95	95	96	97	84	95	89	96	81	96	96	97	96	82	99
90	97	86	87	97	79	97	89	93	99	99	90	95	83	95	90	97	96	87	81	97	97	94	96
92	98	82	97	83	97	83	89	94	97	95	92	83	95	90	95	95	88	88	96	96	87	88	99
92	98	99	98	89	97	97	97	90	96	96	96	96	96	94	92	87	87	96	97	80	88	93	96
92	98	98	83	98	90	96	96	90	95	96	97	96	95	83	94	96	95	97	97	96	96	83	98
92	97	83	95	95	95	94	90	94	91	95	95	88	84	94	95	96	76	95	77	97	97	94	95
92	97	86	88	94	93	96	99	96	99	89	88	90	93	84	88	94	93	84	94	96	95	82	98
92	98	98	97	88	93	94	95	99	97	94	94	95	84	91	94	87	86	90	89	95	81	91	95
92	98	99	98	96	84	94	94	90	95	94	83	95	88	93	89	94	94	94	88	94	86	87	98
92	98	98	73	97	96	82	88	94	94	89	93	96	95	90	93	95	81	94	87	95	94	92	95
92	97	98	97	99	98	95	89	96	84	94	89	94	96	86	87	95	82	93	89	94	86	88	98
92	97	84	80	98	97	88	88	97	96	96	92	81	97	95	87	96	94	80	86	94	89	90	96
92	96	87	96	97	97	84	95	98	97	95	90	95	98	97	88	95	81	95	96	96	91	89	99
92	96	82	96	76	97	95	84	95	88	92	88	96	98	97	81	95	87	96	97	95	83	92	96
92	97	96	77	96	97	82	91	87	92	89	95	75	97	98	96	81	86	96	97	74	94	82	98
93	95	96	95	96	96	95	94	95	95	95	96	95	96	96	96	94	94	95	95	94	95	92	96
98	93	91	91	93	93	94	93	93	94	93	92	92	92	92	92	91	93	93	93	93	92	93	99

